PREMIER®

MANUAL DE INSTRUCCIONES
CAJA FUERTE ELECTRÓNICA
CF-2148

ESTIMADO CLIENTE
Con el fin de que obtenga el mayor desempeño de su producto, por favor lea este manual de instrucciones cuidadosamente antes de comenzar a utilizarlo, y guárdelo para su futura referencia. Si necesita soporte adicional, no dude en escribir a: ***info@premiermundo.com***

LÍNEAS DE SERVICIO AL CLIENTE PREMIER

Venezuela:	0800 – ELECTRIC (353-2874)
Colombia:	01-900-331-PEJC (7352)
Panamá:	300-5185
Sitio Web:	www.premiermundo.com
E-mail:	servicioalcliente@premiermundo.com

NOTA
Nos reservamos el derecho de modificar las especificaciones, características y/u operación de esta unidad sin previo aviso, con el fin de continuar las mejoras y desarrollo del mismo.

INSTRUCCIONES DE LA CAJA FUERTE ELECTRÓNICA

ABRA LA CAJA FUERTE

Ingrese 159. Presione el botón “A” o “B”, gire la perilla cuando la luz este en verde esta abierta, tire para abrir la caja fuerte.

CERRAR LA CAJA FUERTE

Gire La perilla en el sentido contrario de las manecillas del reloj.

CAMBIAR EL CÓDIGO DE SEGURIDAD

Abra la caja fuerte, presione el botón rojo el cual esta ubicado en el respaldo de la puerta, ingrese el código nuevo (3-8 Dígitos) y presione A o B, si el nuevo código ingresado es correcto el zumbador emitirá un zumbido una vez, si el zumbido suena 3 veces entonces usted deberá de intentarlo nuevamente.

ABRIR LA CAJA DE FUERTE CON UNA LLAVE DE EMERGENCIA

Retire la cubierta del logo en la mitad del teclado, inserte la llave de emergencia y gírela a la izquierda y después gire la perilla a la derecha para abrir la puerta.

CAMBIAR LA BATERÍA

Si la luz roja esta encendida con la luz verde, esto indica que indica que usted debería cambiar las baterías, asegurese que la batería esta instalada correctamente, por favor realice una prueba antes de cerrar su caja fuerte.

Nota: Por favor no deje su llave de emergencia dentro de la caja de seguridad.

PREMIER®

INSTRUCTION MANUAL

ELECTRONIC SAFE BOX

CF-2148

DEAR CUSTOMER

In order to achieve the best performance of your product, please read this instruction manual carefully before using, and keep it for future reference.
If you need extra support, please write to ***info@premiermundo.com***

INSTRUCTION OF ELECTRONIC SAFE

PREMIER CUSTOMER SERVICE

Venezuela:	0800 – ELECTRIC (353-2874)
Colombia:	01-900-331-PEJC (7352)
Panama:	300-5185
Website	www.premiermundo.com
E-mail:	servicioalcliente@premiermundo.com

NOTE
This unit may be submitted to changes in specifications, characteristics and/or operation without prior notice to the user, in order to continue improving and developing its technology.

OPEN THE SAFE

Input 159. Press "A" or "B" button. Rotate knob when green light is on. Pull to open the safe.

CLOSE THE SAFE

Turn the knob (key) anti-clockwise to close the safe.

CHANGE THE CODE

Open safe. Press red button which is located at the back of the door. Input the new code (3-8 digit) and press A or B. If new code entered is correct the buzzer will beep once. If it beeps thrice then you should try again.

OPEN THE SAFE WITH EMERGENCY KEY

Remove the logo cover in the middle of the keypad, insert the emergency key and turn to left then rotate the knob(key)to right to open the door.

CHANGE THE BATTERY

If the red light is on with green light indicating that you should change the battery. Make sure the battery is installed correctly. Please have a test before you close the door.

Note: Please do not leave your emergency key into your safe.